


USB-C Dual Adapter

HDMI & VGA




Inhaltsverzeichnis / Table of Contents

Anleitung Deutsch: macOS	2
Quick Start Guide English: macOS.....	13
Anleitung Deutsch: Windows OS	24
Quick Start Guide English: Windows OS	30

Anleitung deutsch: macOS

Schritt 1



SM76x Driver Download

Windows

OS Description	Version	Release Date	Download
Windows 7,8.1 and 10 32-bit and 64-bit Driver	V2.8 R03	Sep 28, 2021	Download

macOS


OS Description	Version	Release Date	Download
Recommended: InstantView display application with UI. Support macOS 12 Monterey, 11 Big Sur and 10.15 Catalina including Apple M1/M1 Pro MacBooks	V2.8 R02	Sep 28, 2021	Download
Legacy Display Driver for macOS 10.15 Catalina, 10.14 Mojave and 10.13 High Sierra	V2.2.16.0	Jun 3, 2021	Download
Legacy Display Driver for macOS 10.10, 10.11 and 10.12	V2.1.4.0201	Dec 12, 2019	Download

Android


OS Description	Version	Release Date	Download
Android 7.1 and above	V2.8.3.0	Sep 28, 2021	Download

QR code and Google Play logo are also visible in the Android section.

 Stellen Sie sicher, dass der Adapter an Ihrem Computer angeschlossen ist.



 Laden Sie die neueste Version von InstantView unter diesem Link herunter:
<https://www.siliconmotion.com/downloads/index.html>



Schritt 2




🔧 Wählen Sie „Erlauben“, um den Treiber von siliconmotion.com herunterzuladen.

Schritt 3




-  Im Ordner Downloads finden Sie den heruntergeladenen Treiber. Öffnen Sie diesen mit einem Doppelklick.
-  Ziehen Sie „macOS InstantView“ in den Ordner „Programme“.




Schritt 4




- 🔑 Navigieren Sie über den Finder in den Programme-Ordner. Öffnen Sie dort das Programm macOS InstantView.

Schritt 5




-  Wählen Sie „Öffnen“, damit das Programm startet.
-  Klicken Sie auf „Open System Preferences“.
-  Wenn Sie auf „Deny“ klicken, wird der Treiber nicht installiert und der LMP Dual Adapter kann nicht funktionieren!

Schritt 6



- 🔧 Die Systemeinstellungen öffnen automatisch unter **Sicherheit & Datenschutz > Datenschutz > Bildschirmaufnahme**. Klicken Sie auf das Schloss und geben Sie das geforderte Passwort Ihres Computers ein.
- 🔧 Klicken Sie auf das Kästchen links neben dem macOS InstantView Icon an.

Schritt 7



 Klicken Sie auf „Beenden & erneut öffnen“. InstantView ist nun vollständig installiert.

Schritt 8



- 🔨 Sobald Sie auf „Connect“ klicken, können Sie bis zu zwei externe Monitore mit Ihrem Mac M1 Gerät verbinden.

Schritt 9



- 🔧 Sie können das Programm über das InstantView Menü (rechts oben in der Anzeigeleiste) beenden.


Fehlerbehebung



🔧 Stecken Sie den Adapter aus und verbinden Sie diesen erneut.

Quick Start Guide English: macOS

Step 1



SM76x Driver Download


Windows

OS Description	Version	Release Date	Download
Windows 7,8.1 and 10 32-bit and 64-bit Driver	V2.8 R03	Sep 28, 2021	Download

macOS

OS Description	Version	Release Date	Download
Recommended: InstantView display application with UI. Support macOS 12 Monterey, 11 Big Sur and 10.15 Catalina including Apple M1/M1 Pro MacBooks	V2.8 R02	Sep 28, 2021	Download
Legacy Display Driver for macOS 10.15 Catalina, 10.14 Mojave and 10.13 High Sierra	V2.2.16.0	Jun 3, 2021	Download
Legacy Display Driver for macOS 10.10, 10.11 and 10.12	V2.1.4.0201	Dec 12, 2019	Download


Android


OS Description	Version	Release Date	Download
Android 7.1 and above	V2.8.3.0	Sep 28, 2021	Google Play  Download

 Please ensure that the adapter is connected to the device.


 Download the latest version of InstantView from this website:
<https://www.siliconmotion.com/downloads/index.html>



Step 2




 Allow downloads from www.siliconmotion.com.

Step 3




-  You can find the downloaded file in the „Downloads“ folder. Open it with a double click.
-  Drag „macOS InstantView“ to „Applications“.




Step 4




 Navigate to the Applications folder in Finder and double click macOS InstantView.

Step 5




-  Press „Open“ to launch the application.
-  Click „Open System Preferences“.
-  The LMP Dual Adapter won't work if you choose „Deny“.

Step 6



- 🔧 System Preferences will open up in **Security & Privacy > Privacy > Screen Recording**. Click on the Lock symbol and enter your password.
- 🔧 Select the checkbox next to the macOS InstantView icon.

Step 7



 Click „Quit & Reopen“. InstantView is now available to use.

Step 8



🔧 Click „Connect“ and you can now use two external monitors with your Mac M1 computer.

Step 9



 You can disconnect by clicking on the InstantView menu button.


Troubleshooting



- 🔧 Unplug the adapter and then reconnect it to your computer.

Anleitung Deutsch: Windows OS


Schritt 1






SiliconMotion

SM76x Driver Download

Windows

OS Description	Version	Release Date	Download
Windows 7,8,1 and 10 32-bit and 64-bit Driver	V2.8 R03	Sep 28, 2021	


macOS

OS Description	Version	Release Date	Download
Recommended: InstantView display application with UI. Support macOS 12 Monterey, 11 Big Sur and 10.15 Catalina including Apple M1/M1 Pro MacBooks	V2.8 R02	Sep 28, 2021	
Legacy Display Driver for macOS 10.15 Catalina, 10.14 Mojave and 10.13 High Sierra	V2.2.16.0	Jun 3, 2021	
Legacy Display Driver for macOS 10.10, 10.11 and 10.12	V2.1.4.0201	Dec 12, 2019	


Android


OS Description	Version	Release Date	Download
----------------	---------	--------------	----------

 Stellen Sie sicher, dass der Adapter an Ihrem Computer angeschlossen ist.


 Laden Sie die neueste Version von InstantView unter diesem Link herunter:
<https://www.siliconmotion.com/downloads/index.html>

Schritt 2




-  Navigieren Sie im Explorer zum „Downloads“ Ordner. Öffnen Sie die heruntergeladene ZIP-Datei mit einem Doppelklick.




Schritt 3




 Sobald Sie die Datei entpackt haben, öffnen Sie das Programm.

Schritt 4



-  Wählen Sie „INSTALL“ um die Installation zu beginnen.
-  Aktivieren Sie das Kästchen, um „Silicon Motion, Inc“ immer zu vertrauen und klicken anschliessend auf „Installieren“.
-  Wenn Sie auf „Nicht installieren“ klicken, wird der Adapter nicht funktionieren!


Schritt 5



- ⚠ Wählen Sie „EXIT“ um die Installation zu beenden.
- ⚠ Der LMP Dual Adapter kann nun verwendet werden.


Quick Start Guide English: Windows OS

Step 1






SM76x Driver Download

Windows

OS Description	Version	Release Date	Download
Windows 7,8,1 and 10 32-bit and 64-bit Driver	V2.8 R03	Sep 28, 2021	

macOS

OS Description	Version	Release Date	Download
Recommended: InstantView display application with UI. Support macOS 12 Monterey, 11 Bug Sir and 10.15 Catalina including Apple M1/M1 Pro MacBooks	V2.8 R02	Sep 28, 2021	
Legacy Display Driver for macOS 10.15 Catalina, 10.14 Mojave and 10.13 High Sierra	V2.2.16.0	Jun 3, 2021	
Legacy Display Driver for macOS 10.10, 10.11 and 10.12	V2.1.4.0201	Dec 12, 2019	


Android


OS Description	Version	Release Date	Download
----------------	---------	--------------	----------

 Please ensure that the adapter is connected to your computer.


 Download the latest version of InstantView from this website:
<https://www.siliconmotion.com/downloads/index.html>


Step 2




 In Explorer, navigate to the „Downloads“ folder and double click the downloaded ZIP file.




Step 3




 Once you have unzipped the driver, open the application.

Step 4



-  Press „INSTALL“ to start the installation.
-  Mark the checkbox to grant access for „Silicon Motion, Inc“, and click „Install“.
-  The LMP Dual Adapter won't work if you choose „Don't Install“.

Step 5



- ⚠ Press „EXIT“ to close the the installation menu.
- ⚠ The LMP Dual Adapter will now be ready to use.